279

UES EVA

Originally Issued: 05/10/2013 Revised: 06/30/2017 Valid Through: 06/30/2018

EVALUATION SUBJECT: HELIX 5-25 MICRO-REBAR CONCRETE REINFORCEMENT SYSTEM

REPORT HOLDER:

Pensmore Reinforcement Technologies, LLC d.b.a. Helix Steel
2300 Washtenaw Ave
Suite 201
Ann Arbor, MI 48104
734-322-2114
www.helixsteel.com

www.helixsteel.com info@helixsteel.com

CSI Division: 03 00 00 - CONCRETE

CSI Section: 03 20 00 - CONCRETE REINFORCEMENT

1.0 SCOPE OF EVALUATION

1.1 Compliance to the following codes & regulations:

- 2015, 2012 and 2009 International Building Code® (IBC)
- 2015, 2012 and 2009 International Residential Code® (IRC)

1.2 Evaluated in Accordance with:

- IAPMO UES EC015-2016, Adopted -November 2013, Revised - January 2016
- ICC-ES AC208, approved October 2005, editorially revised January 2016

1.3 Properties Assessed:

- Shrinkage and temperature crack control in concrete
- Structural tension and shear resistance in concrete
- Fire Resistance

2.0 PRODUCT USE

Helix 5-25 Micro-Rebar functions as tensile reinforcement for concrete.

- **2.1** Helix Micro-Rebar may be used to reduce shrinkage and temperature cracking of concrete. Helix Micro-Rebar may be used as an alternative to the shrinkage and temperature reinforcement specified in Section 24.4 and Chapter 14 of ACI 318-14 and Section 7.12 and Chapter 22 of ACI 318-11 and ACI 318-08 (as referenced in Section 1901.2 of the IBC and Sections R404.1.2 and R611.1 of the IRC).
- 2.2 Helix Micro-Rebar may be used as tension and shear reinforcement in other structural concrete as detailed in this report, which satisfies the requirements of ACI 318-14 Section 1.10, ACI 318-11 Section 1.4 and Section 104.11 of the IBC and IRC.

2.3 Use in Seismic Design Categories C, D, E, and F is subject to the restrictions listed in Section 5.2 of this report.

3.0 PRODUCT DESCRIPTION

Helix 5-25 Micro-Rebar reinforced concrete consists of two materials, as described in Sections 3.1 and 3.2 of this report.

- **3.1 Product Information:** Helix 5-25 Micro-Rebar is made from cold-drawn, deformed wire complying with ASTM A 820, Type I. The steel wire has a tensile strength of 268.3 ksi +/- 21.8 ksi (1850 MPa +/-150 MPa) and a minimum of 3 g/m² zinc coating. The length (1) is 1.0 inch +/- 0.1 inch (25 mm +/- 0.004 mm), equivalent diameter is 0.020 inch +/-0.007 inch (0.5 mm +/- 0.02 mm), and cross sectional area is 0.0003 square inches (0.196 mm²). Each Helix Micro-Rebar has a minimum of one 360-degree twist. Helix Micro-Rebars are packaged in 22.5 pound (10.2 kg) boxes, 45-pound (20.4 kg) boxes or 2450-pound (1111 kg) bags.
- **3.2** Normal Weight Concrete with a minimum 28day compressive strength of 3,000 psi (20.67 MPa).

4.0 DESIGN AND INSTALLATION

4.1 Design Class Selection: The Helix design class shall be selected based on the application and consequence of failure. The registered design professional shall select the design class based on the criteria in Sections 4.2 through 4.5 of this report. Figure 1 of this report provides guidance in making the design class selection.

4.2 Class A – Shrinkage and Temperature Reinforcement

- **4.2.1** Helix 5-25 Micro-Rebar replaces deformed reinforcement bars (rebar) or welded wire reinforcement for shrinkage and temperature reinforcement specified in Section 24.4 of ACI 318-14 and Section 7.12 of ACI 318-11 and ACI 318-08 in members complying with the requirements of Section 14.1.3 (a or b) of ACI 318-14 and Section 22.2.1 (a or b) of ACI 318-11 and ACI 318-08. This application includes plain concrete structures designed in accordance with Chapter 14 of ACI 318-14 or Chapter 22 of ACI 318-11 and ACI 318-08 (as referenced in Section 1901.2 of the IBC and Sections 404.1.3 and R608.1 of the 2015 IRC or Sections 404.1.2 and R611.1 of the 2012 or 2009 IRC).
- **4.2.2** Helix 5-25 Micro-Rebar replaces shrinkage and temperature reinforcement in non-composite stay in place form steel deck applications.
- **4.2.3** Helix 5-25 Micro Rebar may be used in any concrete structure where reinforcement is not required by the IBC or

ANSI Accredited Program

The product described in this Uniform Evaluation Service (UES) Report has been evaluated as an alternative material, design or method of construction in order to satisfy and comply with the intent of the provisions of the code, as noted in this report, and for at least equivalence to that prescribed in the code in quality, strength, effectiveness, fire resistance, durability and safely, as applicable, in accordance with IBC Section 104.11. This document shall only be reproduced in its entirety.



Originally Issued: 05/10/2013 Revis

Revised: 06/30/2017

Valid Through: 06/30/2018

279

IRC or addition to reinforcement required by the IBC or IRC to reduce shrinkage and temperature cracking of the concrete.

4.3 Class B - Minimum Structural Reinforcement

- **4.3.1** Helix 5-25 Micro-Rebar replaces structural reinforcement in soil-supported structures including footings, and foundations.
- **4.3.2** Helix 5-25 Micro-Rebar replaces structural reinforcement in arch structure members in which arch action provides compression in the cross-section.
- **4.3.3** Helix 5-25 Micro-Rebar replaces structural reinforcement in structural concrete slabs supported directly on the ground designed in accordance with ACI 318.
- **4.3.4** Helix 5-25 Micro-Rebar replaces structural reinforcement in pile-supported slabs on ground designed in accordance with ACI 318, with unoccupied space below not to exceed the slab thickness (so failure will not result in structural collapse endangering occupants).
- **4.3.5** Helix 5-25 Micro-Rebar replaces reinforcement in above and below grade structural walls designed in accordance with Chapter 11 of ACI 318-14 and Chapter 14 of ACI 318-11 and ACI 318-08 and conforming to the following criteria:
 - Bearing walls support more than 200 pounds per linear foot (2919 N/m) of vertical load in addition to its own weight. Non-bearing walls support no more than 200 pounds per linear foot (2919 N/m) of vertical load in addition to its own weight.
 - Minimum wall thickness shall be in accordance with the following:

Wall Type	Minimum thickness				
		4in. (100 mm)			
Non-bearing	Greater	1/24 the lesser of			
Non-bearing	of;	unsupported			
		length and height			
		$5^{1}/_{2}$ in. (140 mm)			
Bearing	Greater of;	1/24 the lesser of			
Dearing		unsupported			
		length and height			
		$7^{1}/_{2}$ in. (180 mm)			
Exterior basement	Greater	1/24 the lesser of			
and foundation	of;	unsupported			
		length and height			

 Walls shall be braced against lateral translation (walls shall be laterally supported in such a manner as to prohibit relative lateral displacement at top and bottom or on both sides of individual wall elements). • At least one No. 5 (16 mm) bar shall be provided around all window, door and similar sized openings. The bars shall be anchored to develop fy in tension at the corners of openings.

For residential walls designed in accordance with ACI 318 Chapter 14 or the IBC, Section 4.3.6 of this report also applies.

- **4.3.6** Helix 5-25 Micro-Rebar replaces reinforcement in above and below grade structural walls designed in accordance with the IRC and conforming to the following criteria:
- Bearing walls support more than 200 pounds per linear foot (2919 N/m) of vertical load in addition to its own weight. Non-bearing walls support no more than 200 pounds per linear foot (2919 N/m) of vertical load in addition to its own weight.
- Walls shall be braced against lateral translation (walls shall be laterally supported in such a manner as to prohibit relative lateral displacement at top and bottom or on both sides of individual wall elements).
- Minimum wall thickness shall be in accordance with the following:

Wall Type	Minimum thickness				
		4in. (100 mm)			
Bearing and	Greater	1/24 the lesser of			
non-bearing	of;	unsupported			
		length and height			
		6 in. (150 mm)			
Exterior basement	Greater	1/24 the lesser of			
and foundation	of;	unsupported			
		length and height			

- The effective height shall be used to calculate the height to thickness ratio for 4-inch (100 mm) bearing walls when poured monolithic (i.e. wall is rotationally restrained with a moment connection, even if cold joint is present, at the bottom or top). The effective height is determined by the fixity of the wall end conditions. For walls braced top and bottom against lateral translation and restrained against rotation at one or both ends (top, bottom or both) the effective height shall be 0.8 times the clear height.
- At least one No. 4 (12 mm) bar shall be provided around all window, door, and similar sized openings.
 The bars shall be anchored to develop f_y in tension at the corners of openings.
- **4.3.7** Helix 5-25 Micro-Rebar is used to reinforce slabs-onground designed using non-linear load analysis provided



279

Originally Issued: 05/10/2013 Revised: 06/30/2017 Valid Through: 06/30/2018

maximum tensile strains are limited to levels provided in Section 5.7 of this report.

- **4.4 Class C Structural Concrete:** Helix 5-25 Micro-Rebar replaces structural reinforcement for all other structural concrete including in unsupported horizontal spans.
- **4.5 Class Cs Non-Linear Slab Design:** Helix 5-25 Micro-Rebar shall be used as reinforcement in slabs on ground designed in accordance with ACI 360-10 Section 11.3.3 Methods 2 and 4 when Yield Line Analysis and Nonlinear finite element analysis show tensile strain limits given in Section 5.7 of this report are exceeded. When the tensile strain limits of Section 5.7 are not exceeded, the design shall comply with Section 4.3.7 of this report.
- **4.6 Design:** Helix 5-25 Micro-Rebar dosage quantity shall be determined by procedures in this section and Tables 1, 2 and 3 of this report. Figure 2 of this report, the Helix Force Equilibrium and Strain Compatibility Diagram, shall be observed in the structural design.

4.6.1 Required Area of Steel

- Class A: The required area of steel, A_s, for shrinkage and temperature reinforcement shall be determined by the design procedures in Section 24.4 of ACI 318-14 or Section 7.12 of ACI 318-11 and 318-08 or other applicable code sections.
- Class B and C: The required area of steel reinforcement shall be determined at the centroid of the tension zone (Helix 5-25 Micro-Rebar acts as a rectangular tensile block as shown in Figure 2 of this report) in accordance with standard design procedures in ACI 318 using load and resistance factor design.
- An appropriate strength reduction factor has been applied to the Helix design strength in Tables 1 and 2 of this report.
- **4.6.2 Required Helix Micro-Rebar Quantity:** Table 1 of this report provides the total number of Helix Micro-Rebar required to provide the same tensile resistance as the area of steel computed in Section 4.6.1 of this report. This number shall be divided by the cross-sectional area of the concrete in tension to obtain the number of Helix 5-25 Micro-Rebar required per unit area. This concrete area may result from either direct tension, flexural tension, or shear. Table 1 includes a factor to account for variation on Helix 5-25 Micro-Rebar resistance.
- **4.6.3 Helix 5-25 Micro-Rebar Dosage:** The minimum Helix 5-25 Micro-Rebar dosage required to ensure the number of Helix 5-25 Micro-Rebar per unit area (as determined in Section 4.6.2 of this report) are provided in the tensile region of the concrete shall be selected from Table 2 of this report. This table includes factors to account

for variation in orientation and distribution of Helix 5-25 Micro-Rebar.

4.6.4 Strain in the Helix 5-25 Micro-Rebar Concrete:

Using the provided Helix unit tensile stress provided in Table 3 of this report, the average strain shall be calculated by (Eq.-1):

$$\varepsilon \cong \frac{\text{Helix tensile stress}}{E_{ct}}$$
 (Eq.-1)

Where:

 E_{ct} = the tensile modulus of elasticity of Helix 5-25 Micro-Rebar concrete, computed from Section 19.2 of ACI 318-14 or Section 8.5 of ACI 318-11 and ACI 318-08, as applicable.

 ε = average concrete tensile strain

- **4.6.5 Pre- or post- tensioned concrete:** With pre- or post-tensioned concrete, the initial compressive strain may be subtracted from the average strain calculated in Eq.-1.
- **4.6.6 Restrained shrinkage:** In cases of restrained shrinkage, the shrinkage strain shall be added to the average strain computed in Eq.-1.
- **4.6.7 Shear:** The same method as provided in Sections 4.6.1 to 4.6.6 of this report shall be used for determining shear and torsion reinforcement. The contribution of plain concrete shall be neglected in shear applications (do not add V_c to the shear resistance computed for Helix Micro-Rebar). The area in tension should be taken as no more than the 1.41 x the section width x height minus twice the neutral axis depth. When replacing both bending and shear reinforcement the higher of the two dosages shall govern the design.
- **4.7 Hybrid Design:** Hybrid design includes a combination of deformed reinforcement (rebar) and Helix 5-25 Micro-Rebar. For Hybrid Design, the area of steel computed in accordance with Section 4.6.1 of this report may be reduced by the cross-sectional area of the rebar that will remain prior to determining the required minimum number of Helix Micro-Rebar in Section 4.6.2 of this report.
- **4.7.1** Hybrid design for Class A or B structures have no minimum bar reinforcing requirement provided the application requirements in Sections 4.2 and 4.3 are met and strain limits conform to Section 5.7 of this report.
- **4.7.2** Structures complying with the Class A or B application restrictions in Sections 4.2 and 4.3 of this report but exceeding the strain limits in Section 5.7 may be designed as Class B Hybrid. This process will reduce the strain computed in Section 4.6.5 of this report. The strain limit shall be maintained even if the minimum amount bar reinforcement as prescribed in ACI 318-14 Section 9.6 or ACI 318-11 or ACI-08 Section 10.5 is provided. Alternatively, the registered design professional may elect



Originally Issued: 05/10/2013 Revised: 06/30/2017 Valid Through: 06/30/2018

to use Class C without the need for bar reinforcement.

- **4.7.3** Structures not complying with Class A and B application limitations listed in section 4.2 and 4.3 of this report may be designed as Class C hybrid with a minimum amount of bar reinforcement as prescribed in ACI 318-14 Section 9.6 or ACI 318-11 or ACI 318-08 Section 10.5 except as provided in Section 5.12 of this report.
- **4.7.4** Subject to approval of the code official, the requirement for bar reinforcement in Sections 4.7.2 and 4.7.3 of this report may be waived if registered design professional shows through supplemental testing and/or analysis adequate strength for the factored loads and serviceability requirements.
- **4.7.5** Strength provided by non-composite stay-in-place forms in applications not complying with the Class A and B application limitations may be used to satisfy the minimum reinforcement requirements in Sections 4.7.2 or 4.7.3 provided the registered design professional shows the Helix-reinforced concrete provides resistance equal to or greater than the resistance provided by the required bar reinforcement. The Helix-reinforced design strength, however, shall be adequate to carry the entire load (the contribution of the stay in place forms shall not be added to the capacity).

4.8 Yield Line Methods (ACI 360-10)

The section moment capacity ϕMn shall be calculated using the values in Table 3 of this report. The quantity $\frac{\phi Mn}{S_m \times fr}$ shall replace $\frac{\text{Re},3}{100}$ in ACI 360-10 equations. All other calculations remain the same.

4.9 Fire-Resistance Ratings

- **4.9.1** For flat walls complying with IBC 722.2.1.1, Helix 5-25 Micro-Rebar are permitted as an alternative to the specified reinforcement according to IBC 722.2.1.1. The maximum dosage is 66 lb/yd³ (38 kg/m³).
- **4.9.2** For slabs on metal deck, Helix 5-25 Micro-Rebar are permitted as an alternative or in addition to the welded wire fabric used in concrete members under Underwriters Laboratories Design Nos. G256 dated January 6, 2014 and G514 dated October 11, 2013. The maximum dosage is 66 lb/yd³ (38 kg/m³).

5.0 CONDITIONS OF USE

The Helix 5-25 Micro-Rebar described in this report comply with, and/or are suitable alternatives to what is specified in those codes listed in Section 1.0 of this report, subject to the following conditions:

5.1 The concrete with Helix 5-25 Micro-Rebar shall comply with the ASTM C1116, Type I requirements. Substitution of

any other steel fiber for Helix 5-25 is not allowed.

- **5.2** Structures complying with the requirements of Class A, B and Cs (Section 4.1) are allowed in all seismic design categories permitted by the IBC for these applications. Class C structures in Seismic Design Categories C, D, E, and F are outside of the scope of this report.
- **5.3** Helix Micro-Rebar shall be blended into the concrete mix in accordance with Section 4.0 of this report, ACI 304R or ACI 318-11 and ACI 318-08 Section 5.8, as applicable, and the manufacturers published installation instructions. If there is a conflict between the evaluation report and the manufacturer's published installation instructions, the more restrictive governs.
- **5.4** Concrete used in classes A, B and Cs shall be normal weight and have a minimum compressive strength of 3,000 psi (20.67 MPa) and a maximum compressive strength of 8,000 psi (55.12 MPa).
- **5.5** The Helix Micro-Rebar shall not be used to replace any joints specified in ACI 318-14 Section 14.3 and ACI 318-11 and ACI 318-08 Section 22.3, as applicable.
- **5.6** Concrete used in Class C structures shall be normal-weight and have a minimum compressive strength of 4,000 psi (27.56 MPa) and a maximum compressive strength of 8,000 psi (55.12 MPa) and the mix shall have minimum fine to total aggregate ratio of 0.50 to assure adequate bond with the Helix Micro-Rebar.
- **5.7** Class A and B Strain Limits: The average tensile strain in the concrete shall not exceed the following:

Number of Helix per area	Tensile Strain, ε
Less than 3 Helix/in ²	0.000076
(4,650 Helix/m ²) 3 to 7 Helix/in ²	0.000105
(4,650 to 10,850 Helix/m ²)	0.000103
Greater than 7 Helix/in ²	0.000110
$(10,850 \text{ Helix/m}^2)$	

- **5.8** Hybrid design in accordance with Section 4.7 of this report is allowed for Class A structures complying with Section 4.2 of this report and B structures complying with Section 4.3 of this report, with no minimum reinforcing bar requirement, provided strain limits comply with Section 5.7 of this report.
- **5.9** Helix 5-25 Micro-Rebar shall be limited to the following dosages:

5.9.1 Class A:

Minimum 9 lb/yd³ (5.4 kg/m³) Maximum 70 lb/yd³ (42 kg/m³) Except for slab on ground applications designed as



279

Originally Issued: 05/10/2013 Revised: 06/30/2017 Valid Through: 06/30/2018

360-10 Chapter 7, the minimum dosage does not apply.

5.9.2 Class B:

Minimum 9 lb/yd³ (5.4 kg/m³) Maximum 70 lb/yd³ (42 kg/m³)

5.9.3 Class C:

Minimum 15 lb/yd³ (9 kg/m³) Maximum 70 lb/yd³ (42 kg/m³)

5.9.4 Class Cs:

Minimum 20 lb/yd³ (12 kg/m³) Maximum 70 lb/yd³ (42 kg/m³)

- **5.10** For flexure, standard balanced and tension-controlled limits as prescribed in ACI 318-14 Section 21.2 ACI 318-11 and ACI 318-08 Section 10.3 apply.
- **5.11** A registered design professional shall approve use of Helix 5-25 Micro-Rebar.
- **5.12** Unsupported horizontal spans (free-spanning beams or slabs) with occupied space above or beneath shall have the minimum amount of bar reinforcement required to carry nominal service loads.
- **5.13** Helix 5-25 Micro Rebar shall not be used to replace supplemental rebar placed around openings and tied to lifting points in either cast-in-place or precast concrete.
- **5.14** Helix 5-25 Micro-Rebar shall be added to the concrete either at the ready-mix plant or at the jobsite. The manufacturer's published installation instructions and this report shall be strictly adhered to, and a copy of the manufacturer's published installation instructions shall be available at all times on the jobsite or the batch plant during installation. Installation instructions are available by clicking here.
- **5.15** When Helix 5-25 Micro-Rebar is added at the readymix plant, a batch ticket signed by a ready-mix representative shall be available to the code official upon request. The delivery ticket shall include, in addition to the items noted in ASTM C 94, the type and amount of Helix Micro-Rebar added to the concrete mix.
- **5.16** Field verification of Helix 5-25 Micro-Rebar dosage not required for Class A, B and Cs or in applications designed with the minimum quantity of structural reinforcing bars in accordance with ACI 318. When verification is required, such as for Class C structures and as otherwise specified, the procedures in Appendix A shall be observed.
- **5.17** Helix Micro-Rebar is manufactured under a worldwide exclusive license by Pensmore Reinforcement Technologies, LLC d.b.a Helix Steel.

6.0 SUBSTANTIATING DATA

- Data in accordance with the ICC-ES Acceptance Criteria for Steel Fibers in Concrete (AC208), dated October 2005, editorially revised November 2012.
- Data in accordance with IAPMO UES Acceptance Criteria for Twisted Steel Micro-Rebar (EC 015-2016), Adopted November 2013, Revised January 2016).

7.0 FIGURES, TABLES AND EXAMPLES

Figures (Attached)

- Figure 1: Helix Design Class Selection Flow Chart
- Figure 2: Helix Force Equilibrium and Strain Compatibility Diagram

Tables (Attached)

- Table 1: Helix micro rebar replacement
- Table 2: Helix micro rebar dosage rate
- Table 3: Helix micro rebar tensile force

Examples Calculations (Attached)

- Example 1: Class A Slab on Grade Design Original Rebar Design Given
- Example 2: Class A Slab on Metal Deck Original Mesh Given
- Example 3: Class B Wall Design Minimum Reinforcement Ratio Given
- Example 4: Class B Grade Beam Shear Design Only Original Shear Rebar Given
- Example 5: Class B Wall Design Hybrid

8.0 APPENDICIES

- A. Optional Field Dosage Verification Method
- B. Minimum Helix Dosage Quick Reference



Number:

279

Originally Issued:

05/10/2013

Revised: 06/30/2017

Valid Through: 06/30/2018

9.0 IDENTIFICATION

Labels on the boxes or bags bear the name Helix 5-25 and the number of the IAPMO UES evaluation report number (ER-279), which identifies the product listed in this report. Either Mark of Conformity may be used as shown below:





IAPMO ER #279

Brian Gerber, P.E., S.E. Vice President, Technical Operations Uniform Evaluation Service

Richard Beck, PE, CBO, MCP Vice President, Uniform Evaluation Service

> GP Russ Chaney / CEO, The IAPMO Group

For additional information about this evaluation report please visit www.uniform-es.org or email at info@uniform-es.org

279



Originally Issued: 05/10/2013 Revised: 06/30/2017 Valid Through: 06/30/2018





Figure 1 - Helix Design Class Selection Flow Chart



Where

M is the required moment capacity of the section calculated per ACI 318. If considering a previously designed section, $M = \phi M_n$. Otherwise, $M = M_u$, where M_u is the factored moment of the section based upon loading.

 A_s is the area of steel required at the center of the tension zone (per section 4.6.1) $F_{H=}$ A_s x f_y

fy is the specified yield strength of the reinforcement

 Φ = 1.0 for temperature and shrinkage reinforcement or per applicable code for flexure.

Figure 2: Helix Force Equilibrium and Strain Compatibility Diagram



Number:

279

Originally Issued: 05/10/2013 Revised: 06/30/2017 Valid Through: 06/30/2018

	Table 1: Helix micro rebar replacement - Imperial									
Fy = 60 ksi		Nominal num	nber of Helix M	icro Rebar requ	ired (Helix/ft)					
Nominal	300	0 psi	400	0 psi	500	0 psi				
area of steel										
in tension ΦAs (in²/ft)	Class A R B	Class C 9 Cs	Class A S B	Class C & Cs	Class A S B	Class C 9 Cs				
	Class A & B	Class C & Cs	Class A & B		Class A & B	Class C & Cs				
0.028	37.8 53.6	75.7	37.3	74.6 106.1	36.7 52.5	73.5				
0.040	66.8	107.2 133.5	53.1 66.2	132.4	65.7	105.0 131.3				
0.050	79.9	159.8	79.4	152.4	78.8	157.6				
0.080	106.2	212.4	105.7	211.3	105.1	210.2				
0.080	119.4	238.7	118.8	237.6	118.3	236.5				
0.100	132.5	265.0	132.0	263.9	131.4	262.8				
0.100	145.7	291.3	145.1	290.2	144.6	289.1				
0.110	158.8	317.6	158.3	316.5	157.7	315.4				
0.150 0.160	198.2 211.4	396.5 422.8	197.7 210.9	395.4 421.7	197.2 210.3	394.3 420.6				
	+					420.6				
0.170	224.5 237.7	449.1	224.0	448.0	223.5					
0.180	+	475.4	237.1 263.4	474.3	236.6 262.9	473.2				
0.200	264.0	528.0		526.9		525.8				
0.240	316.6	633.2	316.0	632.1	315.5	631.0				
0.250	329.7	659.5	329.2	658.4	328.6	657.3				
0.300	395.5	791.0	394.9	789.9	394.4	788.8				
0.310	408.6	817.3	408.1	816.2	407.5	815.1				
0.400	527.0	1054.0	526.4	1052.9	525.9	1051.8				
0.440	579.6	1159.2	579.0	1158.1	578.5	1157.0				
0.470	619.0	1238.1	618.5	1237.0	617.9	1235.9				
0.490	645.3	1290.6	644.8	1289.6	644.2	1288.5				
0.500	658.5	1316.9	657.9	1315.8	657.4	1314.8				
0.600	790.0	1579.9	789.4	1578.8	788.9	1577.7				
0.700	921.5	1842.9	920.9	1841.8	920.4	1840.7				
0.760	1000.4	2000.7	999.8	1999.6	999.3	1998.5				
0.780	1026.7	2053.3	1026.1	2052.2	1025.6	2051.1				
0.790	1039.8	2079.6	1039.3	2078.5	1038.7	2077.4				
0.800	1053.0	2105.9	1052.4	2104.8	1051.9	2103.7				
0.900	1184.4	2368.9	1183.9	2367.8	1183.3	2366.7				
0.950	1250.2	2500.4	1249.6	2499.3	1249.1	2498.2				
1.000	1315.9	2631.9	1315.4	2630.8	1314.8	2629.7				
1.090	1434.3	2868.6	1433.7	2867.5	1433.2	2866.4				
1.250	1644.7	3289.3	1644.1	3288.2	1643.6	3287.1				
1.270	1671.0	3341.9	1670.4	3340.8	1669.9	3339.7				
1.550	2039.1	4078.3	2038.6	4077.2	2038.0	4076.1				
1.950	2565.1	5130.2	2564.6	5129.1	2564.0	5128.0				
2.250	2959.6	5919.2	2959.0	5918.1	2958.5	5917.0				
2.330	3064.8	6129.6	3064.2	6128.5	3063.7	6127.4				
3.040	3998.4	7996.8	3997.8	7995.7	3997.3	7994.6				
3.880	5102.9	10205.8	5102.4	10204.7	5101.8	10203.6				
4.000	5260.7	10521.4	5260.2	10520.3	5259.6	10519.2				
4.500	5918.2	11836.3	5917.6	11835.2	5917.1	11834.1				
5.000	6575.6	13151.3	6575.1	13150.2	6574.5	13149.1				
5.500	7233.1	14466.2	7232.5	14465.1	7232.0	14464.0				
6.000	7890.6	15781.1	7890.0	15780.0	7889.5	15778.9				
7.000	9205.5	18411.0	9204.9	18409.9	9204.4	18408.8				



279

Originally Issued: Valid Through: 06/30/2018 05/10/2013 Revised: 06/30/2017

Table 1: Helix micro rehar replacement. Metric

Table 1: Helix micro rebar replacement- Metric									
Fy = 500 Mpa		Nominal numb	er of Helix Mic	ro Rebar requir	ed (Helix/m)				
Nominal area of steel in	20 N	//Ра	30	MPa	40 MPa				
tension Φ As (mm²/m)	Class A & B	Class C & Cs	Class A & B	Class C & Cs	Class A & B	Class C & Cs			
28	70.0	140.0	69.2	138.5	68.4	136.9			
45	111.9	223.8	111.1	222.2	110.3	220.6			
50	124.2	248.4	123.4	246.8	122.6	245.2			
79	195.6	391.3	194.8	389.7	194.0	388.1			
89	220.3	440.5	219.5	438.9	218.7	437.3			
90	222.7	445.4	221.9	443.9	221.1	442.3			
100	247.3	494.7	246.6	493.1	245.8	491.5			
111	274.4	548.9	273.6	547.3	272.9	545.7			
113	279.4	558.7	278.6	557.1	277.8	555.6			
141	348.3	696.7	347.5	695.1	346.7	693.5			
150	370.5	741.0	369.7	739.4	368.9	737.8			
154	380.3	760.7	379.5	759.1	378.8	757.5			
179	441.9	883.8	441.1	882.2	440.3	880.7			
200	493.6	987.3	492.8	985.7	492.0	984.1			
201	496.1	992.2	495.3	990.6	494.5	989.0			
227	560.1	1120.3	559.3	1118.7	558.5	1117.1			
250	616.8	1233.6	616.0	1232.0	615.2	1230.4			
290	715.3	1430.6	714.5	1429.0	713.7	1427.4			
300	739.9	1479.8	739.1	1478.3	738.3	1476.7			
314	774.4	1548.8	773.6	1547.2	772.8	1545.6			
350	863.1	1726.1	862.3	1724.5	861.5	1722.9			
354	872.9	1745.8	872.1	1744.2	871.3	1742.6			
400	986.2	1972.4	985.4	1970.8	984.6	1969.2			
450	1109.3	2218.7	1108.6	2217.1	1107.8	2215.5			
454	1119.2	2238.4	1118.4	2236.8	1117.6	2235.2			
491	1210.3	2420.6	1209.5	2419.1	1208.7	2417.5			
500	1232.5	2465.0	1231.7	2463.4	1230.9	2461.8			
550	1355.6	2711.3	1354.8	2709.7	1354.0	2708.1			
600	1478.8	2957.6	1478.0	2956.0	1477.2	2954.4			
616	1518.2	3036.4	1517.4	3034.8	1516.6	3033.2			
650	1601.9	3203.8	1601.1	3202.2	1600.3	3200.7			
700	1725.1	3450.1	1724.3	3448.5	1723.5	3446.9			
750	1848.2	3696.4	1847.4	3694.8	1846.6	3693.2			
800	1971.3	3942.7	1970.6	3941.1	1969.8	3939.5			
804	1981.2	3962.4	1980.4	3960.8	1979.6	3959.2			
850	2094.5	4189.0	2093.7	4187.4	2092.9	4185.8			
900	2217.6	4435.3	2216.8	4433.7	2216.0	4432.1			
950	2340.8	4681.5	2340.0	4680.0	2339.2	4678.4			
1000	2463.9	4927.8	2463.1	4926.2	2462.3	4924.7			
1100	2710.2	5420.4	2709.4	5418.8	2708.6	5417.2			
1200	2956.5	5913.0	2955.7	5911.4	2954.9	5909.8			
1257	3096.9	6193.7	3096.1	6192.1	3095.3	6190.6			
1300	3202.8	6405.5	3202.0	6404.0	3201.2	6402.4			
1400	3449.1	6898.1	3448.3	6896.5	3447.5	6894.9			
1500	3695.3	7390.7	3694.5	7389.1	3693.8	7387.5			
1963	4835.6	9671.3	4834.8	9669.7	4834.1	9668.1			
2500	6158.2	12316.4	6157.4	12314.8	6156.6	12313.2			



Number:

279

Originally Issued: 05/10/2013 Revis

Revised: 06/30/2017

Valid Through: 06/30/2018

Number of	Table 2: Helix micro rebar dosage rate - Imperial Helix dosage rate, φH _d (lb/yd³)											
Number of Helix per unit area		3000	0 psi		пенх		ιe, φπ _{d (} 0 psi	ib/yū°)		500	0 psi	
in tension (Helix/in²)	Class A	Class B	Class C	Class C _s	Class A	Class B	Class C	Class C _s	Class A	Class B	Class C	Class C _s
1.18	5.5	7.2	6.4	5.5	5.5	7.3	6.6	5.5	5.5	7.5	6.8	5.5
1.25	5.8	7.6	6.8	5.8	5.8	7.7	7.0	5.8	5.8	8.0	7.2	5.8
1.43	6.6	8.7	7.8	6.6	6.6	8.9	8.0	6.6	6.6	9.1	8.2	6.6
1.50	7.0	9.1	8.2	7.0	7.0	9.3	8.4	7.0	7.0	9.6	8.6	7.0
1.53	7.1	9.3	8.3	7.1	7.1	9.5	8.5	7.1	7.1	9.7	8.7	7.1
1.75	8.1	10.6	9.5	8.1	8.1	10.7	9.7	8.1	8.1	11.0	9.9	8.1
2.00	9.3	12.0	10.8	9.3	9.3	12.1	11.0	9.3	9.3	12.4	11.2	9.3
2.25	10.4	13.3	12.1	10.4	10.4	13.4	12.3	10.4	10.4	13.7	12.5	10.4
2.50	11.6	14.7	13.4	11.6	11.6	14.8	13.6	11.6	11.6	15.1	13.7	11.6
2.75	12.8	16.0	14.7	12.8	12.8	16.1	14.9	12.8	12.8	16.6	15.0	12.8
3.00	13.9	17.3	16.0	13.9	13.9	17.4	16.1	13.9	13.9	17.9	16.2	13.9
3.25	15.1	18.6	17.2	15.1	15.1	18.7	17.4	15.1	15.1	19.1	17.5	15.1
3.50	16.2	19.9	18.5	16.2	16.2	20.0	18.6	16.2	16.2	20.6	18.7	16.2
3.75	17.4	21.1	19.7	17.4	17.4	21.2	19.8	17.4	17.4	21.8	19.9	17.4
4.00	18.5	22.4	20.9	18.5	18.5	22.5	21.1	18.5	18.5	22.9	21.2	18.5
4.25	19.7	23.6	22.2	19.7	19.7	23.7	22.3	19.7	19.7	24.3	22.4	19.7
4.50	20.9	24.9	23.4	20.9	20.9	25.0	23.5	20.9	20.9	25.5	23.6	20.9
4.75	22.0	26.1	24.6	22.0	22.0	26.2	24.7	22.0	22.0	26.9	24.8	22.0
5.00	23.2	27.4	25.8	23.2	23.2	27.5	25.9	23.2	23.2	28.3	26.0	23.2
5.25	24.3	28.6	27.0	24.3	24.3	28.7	27.1	24.3	24.3	29.3	27.2	24.3
5.50	25.5	29.8	28.2	25.5	25.5	29.9	28.3	25.5	25.5	30.7	28.4	25.5
5.75	26.7	31.1	29.5	26.7	26.7	31.2	29.5	26.7	26.7	32.1	29.6	26.7
6.00	27.8	32.3	30.7	27.8	27.8	32.4	30.8	27.8	27.8	33.1	30.8	27.8
6.25	29.0	33.5	31.9	29.0	29.0	33.6	32.0	29.0	29.0	34.5	32.1	29.0
6.50	30.1	34.8	33.1	30.1	30.1	34.9	33.2	30.1	30.1	35.9	33.3	30.1
6.75	31.3	36.1	34.3	31.3	31.3	36.1	34.4	31.3	31.3	37.3	34.5	31.3
7.00	32.5	37.4	35.6	32.5	32.5	37.5	35.7	32.5	32.5	38.7	35.8	32.5
7.25	33.6	38.7	36.9	33.6	33.6	38.8	37.0	33.6	33.6	40.0	37.0	33.6
7.50	34.8	40.1	38.2	34.8	34.8	40.1	38.2	34.8	34.8	41.4	38.3	34.8
7.75	35.9	41.4	39.4	35.9	35.9	41.5	39.5	35.9	35.9	42.8	39.6	35.9
8.00	37.1	42.8	40.7	37.1	37.1	42.8	40.8	37.1	37.1	44.2	40.9	37.1
8.25	38.3	44.1	42.0	38.3	38.3	44.2	42.1	38.3	38.3	45.6	42.2	38.3
8.50	39.4	45.4	43.3	39.4	39.4	45.5	43.3	39.4	39.4	46.9	43.4	39.4
8.75	40.6	46.8	44.5	40.6	40.6	46.8	44.6	40.6	40.6	48.3	44.7	40.6
9.00	41.7	48.1	45.8	41.7	41.7	48.2	45.9	41.7	41.7	49.7	46.0	41.7
9.25	42.9	49.4	47.1	42.9	42.9	49.5	47.2	42.9	42.9	51.1	47.3	42.9
9.50	44.0	50.8	48.4	44.0	44.0	50.9	48.4	44.0	44.0	52.5	48.5	44.0
9.75	45.2	52.1	49.6	45.2	45.2	52.2	49.7	45.2	45.2	53.8	49.8	45.2
10.00	46.4	53.5	50.9	46.4	46.4	53.5	51.0	46.4	46.4	55.2	51.1	46.4
10.25	47.5	54.8	52.2	47.5	47.5	54.9	52.3	47.5	47.5	56.6	52.4	47.5
10.50	48.7	56.1	53.5	48.7	48.7	56.2	53.6	48.7	48.7	58.0	53.6	48.7
10.75	49.8	57.5	54.7	49.8	49.8	57.6	54.8	49.8	49.8	59.4	54.9	49.8
11.00	51.0	58.8	56.0	51.0	51.0	58.9	56.1	51.0	51.0	60.7	56.2	51.0
11.25	52.2	60.2	57.3	52.2	52.2	60.2	57.4	52.2	52.2	62.1	57.5	52.2
11.50	53.3	61.5	58.6	53.3	53.3	61.6	58.7	53.3	53.3	63.5	58.7	53.3
11.75	54.5	62.8	59.8	54.5	54.5	62.9	59.9	54.5	54.5	64.9	60.0	54.5
12.00	55.6	64.2	61.1	55.6	55.6	64.3	61.2	55.6	55.6	66.3	61.3	55.6



Number:

279

Originally Issued: 05/10/2013 Revised: 06/30/2017 Valid Through: 06/30/2018

	Table 2: Helix micro rebar dosage rate - Metric												
Number of					Helix d	osage ra	te, φH _d ((kg/m³)					
Helix per		20	MPa			30 MPa				40 MPa			
unit area in	20 1111 0			33 1111 4			40 1011 0						
tension (Helix/m²)	Class A	Class B	Class C	Class C _s	Class A	Class B	Class C	Class C _s	Class A	Class B	Class C	Class C _s	
2000	3.5	4.6	4.1	3.5	3.5	4.8	4.3	3.5	3.5	4.9	4.5	3.5	
2500	4.4	5.8	5.2	4.4	4.4	5.9	5.3	4.4	4.4	6.0	5.5	4.4	
3000	5.3	6.9	6.2	5.3	5.3	7.0	6.4	5.3	5.3	7.1	6.5	5.3	
3500	6.2	7.9	7.2	6.2	6.2	8.0	7.3	6.2	6.2	8.1	7.5	6.2	
4000	7.1	8.9	8.2	7.1	7.1	9.0	8.3	7.1	7.1	9.1	8.5	7.1	
4500	8.0	10.0	9.2	8.0	8.0	10.1	9.3	8.0	8.0	10.1	9.4	8.0	
5000	8.9	10.9	10.1	8.9	8.9	11.0	10.2	8.9	8.9	11.1	10.4	8.9	
5500	9.8	11.9	11.1	9.8	9.8	12.0	11.2	9.8	9.8	12.1	11.3	9.8	
6000	10.6	12.9	12.0	10.6	10.6	13.0	12.1	10.6	10.6	13.1	12.2	10.6	
6500	11.5	13.9	13.0	11.5	11.5	13.9	13.1	11.5	11.5	14.0	13.2	11.5	
7000	12.4	14.8	13.9	12.4	12.4	14.9	14.0	12.4	12.4	15.0	14.1	12.4	
7500	13.3	15.8	14.8	13.3	13.3	15.8	14.9	13.3	13.3	15.9	15.0	13.3	
8000	14.2	16.7	15.8	14.2	14.2	16.8	15.9	14.2	14.2	16.8	15.9	14.2	
8500	15.1	17.7	16.7	15.1	15.1	17.7	16.8	15.1	15.1	17.8	16.9	15.1	
9000	16.0	18.6	17.6	16.0	16.0	18.7	17.7	16.0	16.0	18.7	17.8	16.0	
9500	16.9	19.5	18.6	16.9	16.9	19.6	18.6	16.9	16.9	19.7	18.7	16.9	
10000	17.7	20.5	19.5	17.7	17.7	20.6	19.6	17.7	17.7	20.6	19.6	17.7	
10500	18.6	21.5	20.4	18.6	18.6	21.5	20.5	18.6	18.6	21.6	20.6	18.6	
11000	19.5	22.5	21.4	19.5	19.5	22.6	21.5	19.5	19.5	22.6	21.6	19.5	
11500	20.4	23.5	22.4	20.4	20.4	23.6	22.5	20.4	20.4	23.6	22.5	20.4	
12000	21.3	24.5	23.4	21.3	21.3	24.6	23.4	21.3	21.3	24.7	23.5	21.3	
12500	22.2	25.6	24.3	22.2	22.2	25.6	24.4	22.2	22.2	25.7	24.5	22.2	
13000	23.1	26.6	25.3	23.1	23.1	26.7	25.4	23.1	23.1	26.7	25.5	23.1	
13500	24.0	27.6	26.3	24.0	24.0	27.7	26.4	24.0	24.0	27.7	26.4	24.0	
14000	24.8	28.6	27.3	24.8	24.8	28.7	27.3	24.8	24.8	28.8	27.4	24.8	
14500	25.7	29.7	28.2	25.7	25.7	29.7	28.3	25.7	25.7	29.8	28.4	25.7	
15000	26.6	30.7	29.2	26.6	26.6	30.8	29.3	26.6	26.6	30.8	29.4	26.6	
15500	27.5	31.7	30.2	27.5	27.5	31.8	30.3	27.5	27.5	31.8	30.4	27.5	
16000	28.4	32.8	31.2	28.4	28.4	32.8	31.3	28.4	28.4	32.9	31.3	28.4	
16500	29.3	33.8	32.2	29.3	29.3	33.8	32.2	29.3	29.3	33.9	32.3	29.3	
17000	30.2	34.8	33.1	30.2	30.2	34.9	33.2	30.2	30.2	34.9	33.3	30.2	
17500	31.1	35.8	34.1	31.1	31.1	35.9	34.2	31.1	31.1	35.9	34.3	31.1	
18000	31.9	36.9	35.1	31.9	31.9	36.9	35.2	31.9	31.9	37.0	35.2	31.9	
18500	32.8	37.9	36.1	32.8	32.8	37.9	36.1	32.8	32.8	38.0	36.2	32.8	
19000	33.7	38.9	37.0	33.7	33.7	39.0	37.1	33.7	33.7	39.0	37.2	33.7	
19500	34.6	39.9	38.0	34.6	34.6	40.0	38.1	34.6	34.6	40.0	38.2	34.6	
20000	35.5	41.0	39.0	35.5	35.5	41.0	39.1	35.5	35.5	41.1	39.1	35.5	
20500	36.4	42.0	40.0	36.4	36.4	42.0	40.1	36.4	36.4	42.1	40.1	36.4	
21000	37.3	43.0	41.0	37.3	37.3	43.1	41.0	37.3	37.3	43.1	41.1	37.3	
21500	38.2	44.0	41.9	38.2	38.2	44.1	42.0	38.2	38.2	44.2	42.1	38.2	
22000	39.0	45.1	42.9	39.0	39.0	45.1	43.0	39.0	39.0	45.2	43.1	39.0	
22500	39.9	46.1	43.9	39.9	39.9	46.1	44.0	39.9	39.9	46.2	44.0	39.9	
23000	40.8	47.1	44.9	40.8	40.8	47.2	44.9	40.8	40.8	47.2	45.0	40.8	
23500	41.7	48.1	45.8	41.7	41.7	48.2	45.9	41.7	41.7	48.3	46.0	41.7	
24000	42.6	49.2	46.8	42.6	42.6	49.2	46.9	42.6	42.6	49.3	47.0	42.6	
24500	43.5	50.2	47.8	43.5	43.5	50.2	47.9	43.5	43.5	50.3	47.9	43.5	
25000	44.4	51.2	48.8	44.4	44.4	51.3	48.8	44.4	44.4	51.3	48.9	44.4	



Number:

279

Valid Through: 06/30/2018

Originally Issued: 05/10/2013 Revised: 06/30/2017

Table 3: Helix micro rebar tensile for	rce - Imperial
--	----------------

Normals are of	Table 3: Helix micro rebar tensile force - Imperial Provided Helix unit tensile stress, Fht (psi)											
Number of				Prov	ided Hei			ess, F _{ht} (p	SI)			
Helix per unit area in		300	00 psi			400	0 psi	ı		ı	5000 ps	i
tension (Helix/in²)	Class A	Class B	Class C	Class C _s	Class A	Class B	Class C	Class C _s	Class A	Class B	Class C	Class C _s
1.18	46.2	62.8	23.8	19.2	50.3	68.4	28.9	23.4	54.5	74.7	34.0	27.6
1.25	49.4	67.1	25.8	20.8	53.5	72.7	30.8	25.0	57.7	79.0	35.9	29.2
1.43	57.6	78.2	30.8	24.9	61.7	83.8	35.8	29.1	65.9	90.3	40.9	33.3
1.50	60.8	82.2	32.6	26.5	64.9	87.8	37.7	30.7	69.1	94.7	42.7	34.9
1.53	62.1	83.9	33.4	27.2	66.3	89.5	38.5	31.4	70.5	96.5	43.5	35.6
1.75	72.2	96.2	39.2	32.2	76.4	101.8	44.2	36.4	80.5	108.8	49.2	40.6
2.00	83.6	110.0	45.7	38.0	87.8	115.4	50.7	42.1	91.9	122.6	55.7	46.3
2.25	95.0	123.4	52.1	43.7	99.2	128.9	57.0	47.8	103.3	136.0	62.0	52.0
2.50	106.4	136.7	58.4	49.4	110.6	142.0	63.3	53.5	114.7	149.0	68.2	57.7
2.75	117.8	149.7	64.7	55.1	122.0	155.0	69.6	59.2	126.2	163.8	74.5	63.4
3.00	129.2	162.6	70.9	60.8	133.4	167.8	75.8	64.9	137.6	176.4	80.6	69.1
3.25	140.6	175.3	77.1	66.5	144.8	180.5	81.9	70.6	149.0	188.6	86.7	74.8
3.50	152.1	187.9	83.2	72.2	156.2	193.0	88.0	76.4	160.4	203.0	92.8	80.5
3.75	163.5	200.4	89.3	77.9	167.6	205.5	94.0	82.1	171.8	214.7	98.8	86.2
4.00	174.9	212.8	95.3	83.6	179.0	217.8	100.1	87.8	183.2	226.2	104.8	91.9
4.25	186.3	225.1	101.4	89.3	190.5	230.1	106.1	93.5	194.6	240.3	110.8	97.6
4.50	197.7	237.4	107.4	95.0	201.9	242.4	112.1	99.2	206.0	251.3	116.8	103.3
4.75	209.1	249.6	113.4	100.7	213.3	254.5	118.1	104.9	217.4	265.2	122.7	109.0
5.00	220.5	261.8	119.4	106.4	224.7	266.7	124.0	110.6	228.8	279.1	128.7	114.7
5.25	231.9	273.9	125.3	112.1	236.1	278.8	130.0	116.3	240.3	289.5	134.6	120.5
5.50	243.3	286.1	131.3	117.8	247.5	291.0	135.9	122.0	251.7	303.2	140.6	126.2
5.75	254.7	298.2	137.3	123.5	258.9	303.1	141.9	127.7	263.1	317.0	146.5	131.9
6.00	266.2	310.4	143.2	129.2	270.3	315.2	147.8	133.4	274.5	326.8	152.5	137.6
6.25	277.6	322.5	149.2	134.9	281.7	327.4	153.8	139.1	285.9	340.4	158.4	143.3
6.50	289.0	334.7	155.2	140.6	293.1	339.5	159.8	144.8	297.3	353.9	164.4	149.0
6.75	300.4	347.2	161.2	146.3	304.6	352.0	165.8	150.5	308.7	367.5	170.4	154.7
7.00	311.8	360.4	167.5	152.1	316.0	365.2	172.1	156.2	320.1	381.1	176.7	160.4
7.25	323.2	373.6	173.8	157.8	327.4	378.4	178.4	161.9	331.5	394.7	183.0	166.1
7.50	334.6	386.8	180.1	163.5	338.8	391.6	184.7	167.6	342.9	408.3	189.3	171.8
7.75	346.0	400.0	186.4	169.2	350.2	404.8	190.9	173.3	354.4	421.9	195.5	177.5
8.00	357.4	413.1	192.6	174.9	361.6	418.0	197.2	179.0	365.8	435.4	201.8	183.2
8.25	368.8	426.3	198.9	180.6	373.0	431.1	203.5	184.7	377.2	449.0	208.1	188.9
8.50	380.3	439.5	205.2	186.3	384.4	444.3	209.8	190.5	388.6	462.6	214.4	194.6
8.75	391.7	452.7	211.5	192.0	395.8	457.5	216.1	196.2	400.0	476.2	220.7	200.3
9.00	403.1	465.9	217.8	197.7	407.2	470.7	222.4	201.9	411.4	489.8	226.9	206.0
9.25	414.5	479.1	224.0	203.4	418.7	483.9	228.6	207.6	422.8	503.4	233.2	211.7
9.50	425.9	492.2	230.3	209.1	430.1	497.1	234.9	213.3	434.2	516.9	239.5	217.4
9.75	437.3	505.4	236.6	214.8	441.5	510.3	241.2	219.0	445.6	530.5	245.8	223.1
10.00	448.7	518.6	242.9	220.5	452.9	523.4	247.5	224.7	457.0	544.1	252.1	228.8
10.00	460.1	531.8	249.2	226.2	464.3	536.6	253.8	230.4	468.5	557.7	258.4	234.6
10.50	471.5	545.0	255.5	231.9	475.7	549.8	260.0	236.1	479.9	571.3	264.6	240.3
10.75	482.9	558.2	261.7	237.6	487.1	563.0	266.3	241.8	491.3	584.9	270.9	246.0
11.00	494.4	571.4	268.0	243.3	498.5	576.2	272.6	241.8	502.7	598.4	277.2	251.7
11.25	505.8	584.6	274.3	249.0	509.9	589.4	278.9	253.2	514.1	612.0	283.5	257.4
11.50	517.2	597.7	280.6	254.7	521.3	602.6	285.2	258.9	525.5	625.6	289.8	263.1
11.75	528.6	610.9	286.9	260.4	532.8	615.7	291.5	264.6	536.9	639.2	296.0	268.8
12.00	540.0	624.1	293.1	266.2	544.2	628.9	297.7	270.3	548.3	652.8	302.3	274.5
12.00	J-0.0	024.1	200.1	200.2	J-4.2	020.9	201.1	270.5	270.3	032.0	302.3	214.3



279

Originally Issued: 05/10/2013

Revised: 06/30/2017

Valid Through: 06/30/2018

Table 3: Helix micro rebar tensile force - Metric

Number of	Provided Helix unit tensile stress, Fht (MPa)											
Helix per unit				11001	ucu mem			33, 1 Nt (14	,			
area in		20 N	MPa			30 [ИРа			40 M	lPa	
tension (Helix/m²)	Class A	Class B	Class C	Class C₅	Class A	Class B	Class C	Class C _s	Class A	Class B	Class C	Class C _s
2000	0.35	0.47	0.18	0.15	0.39	0.53	0.23	0.19	0.43	0.59	0.28	0.23
2500	0.45	0.61	0.24	0.20	0.49	0.66	0.29	0.24	0.53	0.72	0.34	0.28
3000	0.55	0.73	0.30	0.25	0.59	0.78	0.35	0.29	0.64	0.84	0.40	0.33
3500	0.65	0.85	0.36	0.30	0.70	0.90	0.41	0.34	0.74	0.96	0.46	0.38
4000	0.76	0.97	0.41	0.35	0.80	1.02	0.46	0.39	0.84	1.07	0.51	0.43
4500	0.86	1.08	0.47	0.40	0.90	1.14	0.52	0.44	0.94	1.19	0.57	0.48
5000	0.96	1.20	0.52	0.45	1.00	1.25	0.57	0.49	1.04	1.30	0.62	0.53
5500	1.06	1.31	0.58	0.50	1.10	1.36	0.63	0.54	1.14	1.41	0.67	0.59
6000	1.16	1.42	0.63	0.55	1.20	1.47	0.68	0.59	1.25	1.52	0.73	0.64
6500	1.26	1.53	0.69	0.60	1.31	1.58	0.73	0.65	1.35	1.63	0.78	0.69
7000	1.37	1.64	0.74	0.65	1.41	1.69	0.79	0.70	1.45	1.74	0.83	0.74
7500	1.47	1.75	0.79	0.71	1.51	1.80	0.84	0.75	1.55	1.85	0.89	0.79
8000	1.57	1.86	0.85	0.76	1.61	1.90	0.89	0.80	1.65	1.95	0.94	0.84
8500	1.67	1.96	0.90	0.81	1.71	2.01	0.95	0.85	1.75	2.06	0.99	0.89
9000	1.77	2.07	0.95	0.86	1.81	2.12	1.00	0.90	1.85	2.17	1.04	0.94
9500	1.87	2.18	1.01	0.91	1.91	2.23	1.05	0.95	1.96	2.28	1.10	0.99
10000	1.97	2.29	1.06	0.96	2.02	2.34	1.10	1.00	2.06	2.38	1.15	1.04
10500	2.08	2.40	1.11	1.01	2.12	2.45	1.16	1.05	2.16	2.50	1.20	1.09
11000	2.18	2.52	1.17	1.06	2.22	2.57	1.21	1.10	2.26	2.61	1.26	1.14
11500	2.28	2.63	1.22	1.11	2.32	2.68	1.27	1.15	2.36	2.73	1.32	1.19
12000	2.38	2.75	1.28	1.16	2.42	2.80	1.33	1.20	2.46	2.85	1.37	1.25
12500	2.48	2.87	1.34	1.21	2.52	2.92	1.38	1.25	2.56	2.97	1.43	1.30
13000	2.58	2.99	1.39	1.26	2.62	3.03	1.44	1.31	2.67	3.08	1.48	1.35
13500	2.68	3.10	1.45	1.31	2.73	3.15	1.49	1.36	2.77	3.20	1.54	1.40
14000	2.79	3.22	1.50	1.37	2.83	3.27	1.55	1.41	2.87	3.32	1.60	1.45
14500	2.89	3.34	1.56	1.42	2.93	3.39	1.61	1.46	2.97	3.43	1.65	1.50
15000	2.99	3.46	1.62	1.47	3.03	3.50	1.66	1.51	3.07	3.55	1.71	1.55
15500	3.09	3.57	1.67	1.52	3.13	3.62	1.72	1.56	3.17	3.67	1.76	1.60
16000	3.19	3.69	1.73	1.57	3.23	3.74	1.77	1.61	3.28	3.79	1.82	1.65
16500	3.29	3.81	1.78	1.62	3.34	3.86	1.83	1.66	3.38	3.90	1.88	1.70
17000	3.40	3.93	1.84	1.67	3.44	3.97	1.89	1.71	3.48	4.02	1.93	1.75
17500	3.50	4.04	1.90	1.72	3.54	4.09	1.94	1.76	3.58	4.14	1.99	1.80
18000	3.60	4.16	1.95	1.77	3.64	4.21	2.00	1.81	3.68	4.26	2.04	1.85
18500	3.70	4.28	2.01	1.82	3.74	4.33	2.05	1.86	3.78	4.37	2.10	1.91
19000	3.80	4.39	2.06	1.87	3.84	4.44	2.11	1.91	3.88	4.49	2.15	1.96
19500	3.90	4.51	2.12	1.92	3.94	4.56	2.16	1.97	3.99	4.61	2.21	2.01
20000	4.00	4.63	2.17	1.97	4.05	4.68	2.22	2.02	4.09	4.73	2.27	2.06
20500	4.11	4.75	2.23	2.02	4.15	4.79	2.28	2.07	4.19	4.84	2.32	2.11
21000	4.21	4.86	2.29	2.08	4.25	4.91	2.33	2.12	4.29	4.96	2.38	2.16
21500	4.31	4.98	2.34	2.13	4.35	5.03	2.39	2.17	4.39	5.08	2.43	2.21
22000	4.41	5.10	2.40	2.18	4.45	5.15	2.44	2.22	4.49	5.20	2.49	2.26
22500	4.51	5.22	2.45	2.23	4.55	5.26	2.50	2.27	4.59	5.31	2.55	2.31
23000	4.61	5.33	2.51	2.28	4.65	5.38	2.56	2.32	4.70	5.43	2.60	2.36
23500	4.71	5.45	2.57	2.33	4.76	5.50	2.61	2.37	4.80	5.55	2.66	2.41
24000	4.82	5.57	2.62	2.38	4.86	5.62	2.67	2.42	4.90	5.66	2.71	2.46
24500	4.92	5.69	2.68	2.43	4.96	5.73	2.72	2.47	5.00	5.78	2.77	2.51
25000	5.02	5.80	2.73	2.48	5.06	5.85	2.78	2.52	5.10	5.90	2.83	2.56



279

Originally Issued: 05/10/2013 Revised: 06/30/2017 Valid Through: 06/30/2018

Example 1: Class A Slab on Grade Design - Original Rebar Design Given

	Class A Slab on Grade Design – Origina	al Rebar Design Given	1
Imperial Units Given: 8" slab on ground with #4 bars @ 14" OCEW mid depth fy = 60000 psi f c= 4000 psi b = 12 in \$\phi\$ = 1.0	Metric Units Given: 254 mm slab on ground with 12mm bars @ 300 mm OCEW mid depth fy = 500 MPa f _c = 30 MPa b =1000 mm φ = 1.0	S S S S S S S S S S S S S S S S S S S	5 30000
Calculation in accordance with ACI 31	8 and this report	Code Reference	Report Reference
Step 1. Class Selection 1 - Slab on ground (Soil supported) 2 - Shrinkage & temperature reinforcement less than ρ = 0.0020 ⇒ Class A	Step 1. Class Selection 1 - Slab on ground (Soil supported), 2 - Shrinkage & temperature reinforcement less than p=0.0020		4.1
Step 2. Compute area of steel required at the center of the section, Φ As = 1.0 x 0.2 x 12/14 in = 0.17 in²/ft ρ = 0.0018 (The rebar configuration is given, but if it were not given, it would be computed based on the loads using standard ACI 318 methods)	Step 2. Compute area of steel required at the center of the section Φ As = 1.0 x 116 x 1000 / 300mm = 377 mm ² /m ρ = 0.0015 (The rebar configuration is given, but if it were not given, it would be computed based on the loads using standard ACI 318 methods)	ACI 318-14 24.4 ACI 318-11 7.12 ACI 318-08 7.12	4.6.1
Step 3. Use Table 1, find the nearest area of steel in column 1 and read the required number of Helix for the appropriate compressive strength: = 224 pieces of Helix Micro Rebar	Step 3. Use Table 1, find the nearest area of steel in column 1 and read the required number of Helix for the appropriate compressive strength: = 985.4 pieces of Helix Micro Rebar		4.6.2 Table 1
Step 4. Divide number of Helix required by the area in tension, A _g = 224/(8x 12 in) = 2.33 Helix per square inch	Step 4. Divide number of Helix required by the area in tension, A _{g:} = 985.4 x 1000 ² /(254*1000 mm) = 3880 Helix per square meter		4.6.2
Step 5. Use Table 2, find the nearest number of Helix per unit area in column 1 and read the required Helix dosage for the appropriate class and compressive strength: Required Helix Dosage 10.9 lb/yd³	Step 5. Use Table 2, find the nearest number of Helix per unit area in column 1 and read the required Helix dosage for the appropriate class and compressive strength: Required Helix Dosage 7.1 kg/m³		4.6.3 Table 2

Number:

279

Originally Issued: 05/10/2013 Revised: 06/30/2017 Valid Through: 06/30/2018

Example 2: Class A Slab on Metal Deck - Original Mesh Given

Imperial Units	Metric Units		
Given: Slab on composite metal deck 5" total thickness, 2"metal deck with 6"x 6"- W2.9 x W2.9 welded wire mesh $f_y = 60000 \text{ psi}$ $f_c = 4000 \text{ psi}$ $b = 12 \text{ in}$ $\phi = 1.0$	Given: Slab on composite metal deck 125 mm total thickness, 50 mm metal deck with welded wire mesh 6mm dia x 200mm spacing $f_y = 500$ MPa $f_c = 30$ MPa $f = 1000$ mm $f = 1.0$	S	S
Calculation in accordance with ACI 318 a	nd this report	Code Reference	Report Reference
Step 1. Class Selection 1 - Slab on composite metal deck 2 - Shrinkage and temperature reinforcement less than ρ=0.0020 ⇒ Class A	Step 1. Class Selection 1 - Slab on composite metal deck 2 - Shrinkage and temperature reinforcement less than p=0.0020		4.1
Step 2. Compute area of steel required at the center of the section Φ As =0.058in ² /ft p=0.0016	Step 2. Compute area of steel required at the center of the section ΦAs =141 mm² /m ρ=0.0019	ACI 318-14 24.4 ACI 318-11 7.12 ACI 318-08 7.12	4.6.1
Step 3. Use Table 1, find the nearest area of steel in column 1 and read the required number of Helix for the appropriate compressive strength: = 79.4 pieces of Helix Micro Rebar	Step 3. Use Table 1, find the nearest area of steel in column 1 and read the required number of Helix for the appropriate compressive strength: = 347.5 pieces of Helix Micro Rebar		4.6.2 Table 1
Step 4. Divide required number of Helix by the gross section area in tension, A _g : = 79.4/(3x12 in) = 2.2 Helix per square inch. Note: the 5" thickness is reduced to 3 inches due to the 2" deep corrugated metal deck.	Step 4. Divide number of Helix required by the gross section area in tension, A _g : = 347.5 x 1000²/(75 x 1000mm) =4633 Helix per square meter. Note: the 125 mm thickness is reduced to 75 mm due to the 50 mm deep corrugated metal deck.		4.6.2
Step 5. Use Table 2, find the nearest number of Helix per unit area in column 1 and read the required Helix dosage for the appropriate compressive strength: Required Helix Dosage 10.4 lb/yd³	Step 5. Use Table 2, find the nearest number of Helix per unit area in column 1 and read the required Helix dosage for the appropriate compressive strength: Required Helix Dosage 8.9 kg/m³.		4.6.3 Table 2



05/10/2013 Revised: 06/30/2017 Valid Through: 06/30/2018 Originally Issued:

Example 3	3: Class B Wall Design –Minimum Reinford	cement Ratio Given	
English/Imperial Units Given:	Metric Units Given: Well 2 6m high x 450 mm thick with		AP.
Wall 12' high x 6" thick with $(\rho_{\text{min}}=0.0025)$ #4 bars @ 12" OCEW -at mid-depth $f_y=60000$ psi $f_c=4000$ psi $b=12$ in $\phi=0.9$ ϕ Mn = 31 kip-in/ft = 31,000 lb-in/ft	Wall 3.6m high x 150 mm thick with $(\rho_{min}$ =0.0025) 12mm bar @300 mm OCEW at mid-depth fy = 500 MPa fc= 30 MPa b =1000 mm ϕ = 0.8 ϕ Mn = 10.8 kN-m/m		5
Calculation in accordance with ACI 318	and this report	Code Reference	Report Reference
Step 1. Class Selection	Step 1. Class Selection		4.1
Vertical structural support	Vertical structural support	ACI 318-14 Section	•••
Slenderness check, h/24	Slenderness check, h/24	14.3.1.1	
=12' x 12"/24 = 6" OK	= 3.6m x 1000mm/24 = 150 OK	ACI 318-11 Section	
⇒ Class B	⇒ Class B	22.6.6.2 ACI 318-08 Section 22.6.6.2	
Step 2. Compute required area of steel	Step 2. Compute required area of steel	ACI 318-14 Cpt. 9	4.6.1 Figure 2
at the center of the tension zone using	at the center of the tension zone using	ACI 219 11 Cpt 10	
equations in Figure 2: Calculate the neutral axis depth, "c".	equations in Figure 2:	ACI 318-11 Cpt. 10 ACI 318-08 Cpt. 10	
c = 0. 0.328"	Calculate the neutral axis depth, "c".	(Rebar given, but if it	
	c = 8.33 mm	were not given it	
Required area of steel = 0.17 in ² /ft at		would be computed	
tension zone center	Required area of steel= 286 mm ² /m	based on the loads	
		using standard ACI 318 methods)	
Step 3. Use Table 1, find the nearest	Step 3. Use Table 1, find the nearest	310 methods)	4.6.2
area of steel in column 1 and read the	area of steel in column 1 and read the		Table 1
required number of Helix for the	required number of Helix for the		
appropriate compressive strength:	appropriate compressive strength:		
= 224 pieces of Helix Micro Rebar Step 4. Divide number of Helix required	= 715 pieces of Helix Micro Rebar. Step 4. Divide number of Helix required		4.6.2
by the area in tension, A_T	by the area in tension, A_T		4.6.2 4.6.1 Figure 2
a, a.e area in terroren, ru			
$A_T = b x (h-c) = 12 x 5.7 = 68.4 in^2$	$A_T = b x (h-c) = 1000mm x (150mm -$		
004//004:2	$8.33 \text{ mm} \times (1 \text{m}/1000 \text{mm})^2 = 0.142 \text{ m}^2$		
= 224/(68.4 in ²)	= 715/ 0.142		
= 3.27 Helix per square inch	= 5035 Helix per square meter		
Step 5. Use Table 2, find the nearest	Step 5. Use Table 2, find the nearest		4.6.3
number of Helix per unit area in column 1	number of Helix per unit area in column 1		Table 2
and read the required Helix dosage for	and read the required Helix dosage for		
the appropriate class and compressive	the appropriate class and compressive		
strength: Required Helix Dosage 18.7 lb/yd³	strength: Required Helix Dosage 11.1 kg/m³		
Step 6. Use Table 3 & result of step 4 to	Step 6. Use Table 3 & result of step 4 to		4.6.4
find Helix tensile stress, = 181 psi	find Helix tensile stress: =1.25 MPa		Table 3
$= 181 \times 10^6 / (57000 \sqrt{4000})$	Strain = $1.25 \times 10^6 / (4700 \sqrt{30})$		
= 50 micro strain	= 49 micro strain		
Step 7. Use result of step 4 to find	Step 7. Use result of step 4 to find		5.7
allowable strain = 105 > 50 OK	allowable strain = 105 > 49 OK		

Valid Through: 06/30/2018 Originally Issued: 05/10/2013 Revised: 06/30/2017

Example 4: Cla	ıss B Grade Beam Shear Design Only – Oriç	ginal Shear Rebar Give	n
English/Imperial Units	Metric Units		
Given: Grade beam 8" thick with #4 bars @12" shear ties. $f_y = 60000 \text{ psi}$ $f_c = 4000 \text{ psi}$ $b = 12 \text{ in}$ $\phi = 0.75$	Given: Grade Beam 200 mm thick with 12mm bars @ 300 mm shear ties. fy = 500 MPa f_c = 40 MPa b =1000 mm ϕ = 0.75		S
Calculation in accordance with ACI 318	and this report	Code Reference	Report Reference
Step 1. Class Selection	Step 1. Class Selection		4.1
⇒ Class B	⇔ Class B		
Step 2. Compute Required Area of Steel for shear resistance, #4@12"(Given).	Step 2. Compute Required Area of Steel for shear resistance, N 12 @300 (Given).		
Step 3. Compute required area of steel assuming rebar inclined at 45 degrees, ϕ As = ϕ A _v x sin(45) x b/s = 0.75 x 0.2 x .707 x 12"/12" = 0.106 in ² /ft	Step 3. Compute required area of steel assuming rebar inclined at 45 degrees, \$\phi As= \phi A_v x \sin(45) x b/s\$ = 0.75 x 113 x 0.707 x1000/300 mm = 200 mm²/m	ACI 318-14 Section 22.5.10.6.2 ACI 318-11 Section 11.4.7.5 ACI 318-08 Section 11.4.7.5	4.6.1
Step 4. Use Table 1, find the nearest area of steel in column 1 and read the required number of Helix for the appropriate compressive strength: = 145.1 pieces of Helix Micro Rebar	Step 4. Use Table 1, find the nearest area of steel in column 1 and read the required number of Helix for the appropriate compressive strength: = 492 pieces of Helix Micro Rebar		4.6.2 Table 1
Step 5. Compute shear area based on diagonal tension plane = h x 1.41 x b = 8 x 1.41 x 12 = 135 in ² /ft	Step 5. Compute shear area based on diagonal tension plane = h x 1.41 x b = 200 x 1.41 x 1000 mm/1000 ² = 0.282 m ² /m		
Step 6. Divide number of Helix required by the shear area, =145.1/135 =1.07 Helix per square inch	Step 6. Divide Number of Helix Required Area, = 492/0.282 = 1745 Helix per square meter		4.6.8
Step 7. Use Table 2, find the nearest number of Helix per unit area in column 1 and read the required Helix dosage for the appropriate class and compressive strength:	Step 7. Use Table 2, find the nearest number of Helix per unit area in column 1 and read the required Helix dosage for the appropriate class and compressive strength:		4.6.3 Table 2
Required Helix dosage 7.3 lb/yd ³ Less than minimum, use 9 lb/yd ³	Required Helix dosage 4.9kg/m³ Less than minimum, use 5 kg/m³		



Number:

279

Originally Issued: 05/10/2013 Revised: 06/30/2017 Valid Through: 06/30/2018

Example 5: Class B Wall Design - Hybrid

	Example 3. Class B Wall Design - Hybr	iu .
English/Imperial Units	Metric Units	
Given: Wall 20' high x 10" thick with 2- Layers #6 bars @ 10" OCEW As = 0.53 in²/ft (ρ = 0.0088) ϕ M = 220 k-in/ft C_c = 1.5 in f_y = 60000 psi f_c = 4000 psi b =12 in ϕ = 0.9	Given: Wall 6m high x 254 mm thick with 2 -Layers 16mm bars @200 mm OCEW As = 1000 mm²/m (ρ=0.0079) φM = 83 kN-m/m C _c = 40 mm fy = 500 MPa f' _c = 30 MPa b =1000 mm φ = 0.8	S

Calculation in accordance with ACI 318 an	•	Code Reference	Report Reference
Step 1. Class Selection Vertical structural support Slenderness check, h/24 =20 x12/24 =10" OK Strain check	Step 1. Class Selection Vertical structural support Slenderness check, h/24 =6 x 1000/24 =250mm OK Strain check		4.1
Rebar Tension= As Fy = 31,800 lb Helix tensile stress= = T [(h-C _c)/(h/2)]/(bh)= = 31,800[1.7]/(10x12)= = 450 psi = 450x10 ⁶ /(57000 $\sqrt{4000}$) = 125 micro strain • Allowable strain	Rebar Tension= As Fy =500000 N Helix tensile stress= = T [(h-C _c)/(h/2)]/(bh)= = 500000[1.7]/(254x1000)= = 3.36 MPa = 3.36 x10 ⁶ /(4700 $\sqrt{30}$) = 130 micro strain		4.6.5
Allowable strain Number of Helix/in²= 8.0 110 micro strain < 125 Not OK ⇔Class B Hybrid	Allowable strain Number of Helix/in²= 8.0 110 micro strain < 130 Not OK ⇔Class B Hybrid		5.7
Step 2.Calculate minimum As As = $3\sqrt{f'c}$ bd/fy = $3\sqrt{4000}$ x 12 x 8.2 / 60000 = 0.31 in ² /ft Use #5 at 12 in = 0.31 in ² /ft	Step 2.Calculate minimum As $As=0.25\sqrt{f'c}$ bd/fy $=0.25\sqrt{30}$ x 1000 x 206 / 500 $=564$ mm² /m use 12mm at 200mm = 550 mm²/m	ACI 318-14 Chapter 9 ACI 318-11 Chapter 10 ACI 318-08 Chapter 10	4.7.2
Step 3. Calculate the moment for the Hybrid rebar φM= φAs x fy x(h/2)=84 k-in/ft	Step 3. Calculate the moment for the Hybrid rebar \$\phi M = \phi As x fy x(h/2) = 28 KN-m/m		
Step 4. Calculate Helix required bending moment \$\phi\$M= 220-84= 136 k-in/ft	Step 4. Calculate Helix required bending moment \$\phi M=83-28 = 55 KN-m/m\$		



Number:

279

Originally Issued: 05/10/2013 Revised: 06/30/2017 Valid Through: 06/30/2018

Example 5: Class B Wall Design - Hybrid

English/Imperial Units	Metric Units	
Given: Wall 20' high x 10" thick with 2- Layers #6 bars @ 10" OCEW As = $0.53 \text{ in}^2/\text{ft}$ (ρ = 0.0088) ϕ M = 220 k-in/ft C_c = 1.5 in f_y = 60000 psi f_c = 4000 psi b =12 in ϕ = 0.9	Given: Wall 6m high x 254 mm thick with 2 -Layers 16mm bars @200 mm OCEW As = 1000 mm ² /m (ρ =0.0079) ϕ M = 83 kN-m/m C_c = 40 mm fy = 500 MPa f_c = 30 MPa b =1000 mm ϕ = 0.8	S

Calculation in accordance with ACI 318 and	d this report	Code Reference	Report Reference
Step 5. Calculate the equivalent area of steel for the bending moment that Helix requires Using equation in Figure 2, calculate the neutral axis depth, "c" c = 0.86" As at tension zone center = 0.448 in²/ft	Step 5. Calculate the equivalent area of steel for the bending moment that Helix requires Using equation in Figure 2, calculate the neutral axis depth, "c" c = 24.9 mm As at tension zone center = 846 mm²/m	ACI 318-14 Chapter 9 ACI 318-11 and ACI 318-08 Chapter 10	4.6.1 Figure 2
Step 6. Use Table 1, find the nearest area of steel in column 1 and read the required number of Helix for the appropriate compressive strength: = 590 pieces of Helix Micro Rebar	Step 6. Use Table 1, find the nearest area of steel in column 1 and read the required number of Helix for the appropriate compressive strength: = 2093 pieces of Helix Micro Rebar.		4.6.2 Table 1
Step 7. Divide number of Helix required by the area in tension, , A_T $A_T = b \times (h-c) = 12 \times 9.1 = 109 \text{ in}^2$ $= 590/109 \text{ in}^2$ $= 5.41 \text{ Helix per square inch}$	Step 7. Divide number of Helix required by the area in tension, A_T $A_T = b \times (h-c) = 1000 \text{mm} \times (254 \text{mm} - 24.9 \text{mm}) \times (1 \text{m}/1000 \text{mm})^2 = 0.229 \text{ m}^2$ $= 2093/0.229$ $= 9140 \text{ Helix per square meter}$		4.6.2
Step 8. Use Table 2, find the nearest number of Helix per unit area in column 1 and read the required Helix dosage for the appropriate class and compressive strength: Required Helix Dosage 29.9 lb/yd³ plus one layer of #5 bars at 12 in on center at mid depth	Step 8. Use Table 2, find the nearest number of Helix per unit area in column 1 and read the required Helix dosage for the appropriate class and compressive strength: Required Helix Dosage 19.0 kg/m³ plus one layer of 12 mm bars at 200 mm on center at mid depth		4.6.3 Table 2
Step 9. Strain check Use Table 3 & result of step 7 to find Helix tensile stress,	Step 9. Strain check Use Table 3 & result of step 7 to find Helix tensile stress: $\phi F_{ht} = 2.23 \text{ MPa}$ Strain = $2.23 \times 10^6 / (4700 \sqrt{30})$ = 87 micro strain		4.6.4 Table 3 4.6.5



279

Valid Through: 06/30/2018 Originally Issued: 05/10/2013 Revised: 06/30/2017

Example 5: Class B Wall Design - Hubrid (Cent'd)

English/Imperial Units	Example 5: Class B Wall Design – Hybrid (C Metric Units	,	
Given: Wall 20' high x 10" thick with 2- Layers #6 bars @ 10" OCEW As = 0.53 in²/ft (ρ = 0.0088) ϕ M = 220 k-in/ft C_c = 1.5 in f_y = 60000 psi f_c = 4000 psi f_c = 4000 psi f_c = 0.9	Given: Wall 6m high x 254 mm thick with 2 -Layers 16mm bars @200 mm OCEW As = 1000 mm 2 /m (ρ =0.0079) ϕ M = 83 kN-m/m C_c = 40 mm fy = 500 MPa f_c = 30 MPa b =1000 mm ϕ = 0.8		
Calculation in accordance with ACI 3	18 and this report	Code Reference	Report Reference
Step 10. Use result of step 7 to find allowable strain = 110 > 81 OK	Step 10. Use result of step 7 to find allowable strain = 105 > 87 OK		5.7



279

05/10/2013 Revised: 06/30/2017 Valid Through: 06/30/2018 Originally Issued:

Appendix A: Field Verification of Helix Dosage by Washout Test

Procedure

Helix content (dosage) verification testing, when required, shall be conducted in accordance with CSA A23.2-16C "Standard Test Method for Determination of Steel or Synthetic Fibre Content in Plastic Concrete". Available for download at http://shop.csa.ca/

Criteria

The average Helix content (CSA A23.2-16C section 9g) shall exceed specified minimum dosages in Tables 1 or 2 below. If dosage verification is required in accordance with Section 5.16 and two consecutive tests fail, corrective action is required prior to continuing the pour.

Conversions Multiply lb/yd3 by 0.59 to obtain oz/ft3 Grams per liter is equal to kg/m3

Table 1 Imperial Unit Limits (9 and 10 yd3 Trucks)

Boxes Of Helix Added to 9 yd ³ Truck	Specified Helix Dosage (lb/yd³)	Minimum Average Helix Dosage (lb/yd³)
1	5	3.6
2	10	7.9
3	15	12.5
4	20	17.4
5	25	22.4
6	30	27.6
7	35	32.8
8	40	38.0
9	45	43.3
10	50	48.5
11	55	53.7
12	60	58.9
13	65	64.0

Boxes Of Helix Added to 10 yd ³	Specified Helix Dosage (lb/yd³)	Minimum Average Helix Dosage
Truck		(lb/yd³)
1	4.5	3.3
2	9	7.0
3	13.5	11.1
4	18	15.4
5	22.5	19.9
6	27	24.5
7	31.5	29.1
8	36	33.8
9	40.5	38.5
10	45	43.3
11	49.5	48.0
12	54	52.6
13	58.5	57.3

Table 2 Metric Unit Limits (7 and 8 m³ Trucks)

Boxes Of	Specified	Minimum
Helix	Helix	Average
Added to	Dosage	Helix
7 m ³	(kg/m³)	Dosage
Truck		(kg/m^3)
1	2.9	2.1
2	5.8	4.5
3	8.8	7.2
4	11.7	10.0
5	14.6	12.9
6	17.5	15.9
7	20.5	18.9
8	23.4	22.0
9	26.3	25.0
10	29.2	28.1
11	32.1	31.1
12	35.1	34.2
13	38.0	37.2
14	40.9	40.2

Boxes Of Helix Added to	Specified Helix Dosage	Minimum Average Helix
8 m ³	(5g/m³)	Dosage
Truck		(kg/m ³)
1	2.6	1.8
2	5.1	4.0
3	7.7	6.3
4	10.2	8.8
5	12.8	11.3
6	15.3	13.9
7	17.9	16.6
8	20.5	19.2
9	23.0	21.9
10	25.6	24.6
11	28.1	27.2
12	30.7	29.9
13	33.2	32.6
14	35.8	35.2

Number:

279

Originally Issued: 05/10/2013 Revised: 06/30/2017 Valid Through: 06/30/2018

Appendix B: Helix 5-25 Micro Rebar Quick Reference Class A and B Dosages

The tables include common welded wire mesh and rebar configurations in concrete 4 - 10 inch (100 - 250 mm) thicknesses along with Helix alternative designs computed in accordance with this report. Class A (Section 4.2) is assumed when reinforcement ratio is less than 0.002, (just above the limit for temperature and shrinkage reinforcement in ACI 318 Section 7.12), otherwise class B (Section 4.3) is assumed (shaded cells). This table shall not be used for class C or Cs design (Section 4.4 and 4.5). The rebar and mesh in these tables is assumed to specified at mid depth and concrete has a 3000 psi (20 MPa) compressive strength. To use the table, find the reinforcement specified in the left hand column and follow to the right until you reach the column corresponding to the specified thickness of the concrete. The number in the cell is the Helix dosage required to replace the mesh or rebar. The tables may be used for design provided a written submittal referencing this report is provided to the code official indicating that the original specifications match the table assumptions, the design class is either A or B and restrictions in section 5 are satisfied.

Common Mesh Arrangements Imperial Units								Common Mesh Arrangements Metric Units					
3000 psi Concrete		4 inch	5 inch	6 inch	7 inch	8 inch	10 inch	20 MPa	Concrete	100 mm	150 mm	200 mm	250 mm
Grade 60 WWF		Minimum Helix 5-25 Micro Rebar Dosage (lb/yd³)					Grade 5	00 WWF	Helix Micro Rebar Dose (kg/m³)				
6x6	W1.4XW1.4	4.5	4.5	4.5	4.5	4.5	4.5	200mm	4.75mm	4.0	3.0	3.0	3.0
6X6	W2.0XW2.0	5.2	4.5	4.5	4.5	4.5	4.5	200mm	6mm	6.4	4.3	3.2	3.0
6X6	W2.9XW2.9	7.5	6.0	5.0	4.5	4.5	4.5	200mm	6.75mm	8.0	5.4	4.0	3.2
6X6	W4XW4	10.3	8.2	6.9	5.9	5.2	4.5	200mm	7.6mm	11.5	6.8	5.1	4.1
4X4	W2.9XW2.9	11.2	9.0	7.5	6.4	5.6	4.5	200mm	8.6mm	14.2	8.6	6.5	5.2
6X6	W5.5XW5.5	15.7	11.3	9.4	8.1	7.1	5.7	200mm	9.5mm		11.9	7.9	6.3
4X4	W4XW4	16.9	13.9	10.3	8.8	7.7	6.2	100mm	7.6mm		14.7	11.5	8.1
4X4	W5.5XW5.5	22.3	18.3	15.7	12.0	10.6	8.5						
Single Layer Rebar Imperial Units								Single Layer Rebar Metric Units					
3000 psi Concrete		4 inch	5 inch	6 inch	7 inch	8 inch	10 inch	20 MPa	20 MPa Concrete		150 mm	200 mm	250 mm
Gra	ide 60 Rebar	Minimum Helix 5-25 Micro Rebar Dosage (lb/yd³)						Grade 500 Rebar Helix Micro Rebar Dose			kg/m³)		
#3	24" OC	7.1	5.7	4.8	4.5	4.5	4.5	10mm	400 mm	8.6	5.8	4.4	3.5
#3	18" OC	9.4	7.6	6.3	5.4	4.8	4.5	10mm	300 mm	12.8	7.7	5.8	4.6
#3	16" OC	10.6	8.5	7.1	6.1	5.3	4.5	10mm	200 mm	18.2	12.8	8.6	6.9
#3	12" OC	15.7	11.3	9.4	8.1	7.1	5.7	12mm	400 mm	13.5	8.1	6.1	4.9
#4	24" OC	14.4	10.3	8.6	7.4	6.4	5.2	12mm	300 mm		12.2	8.1	6.5
#4	18" OC	18.5	15.2	11.4	9.8	8.6	6.9	12mm	200 mm			13.5	11.1
#4	16" OC	20.5	16.9	14.4	11.0	9.6	7.7	16mm	400 mm			12.4	10.2
#4	12" OC	35.0	21.7	18.5	16.7	14.3	10.2	16mm	300 mm				13.2
#5	12" OC		47.2	27.2	23.7	21.1	17.3						

NOTE: If the original design configuration is not listed, the dosage cell is blank or if there is ANY deviation from the assumptions (original bar depth, grade listed in table, thickness, or concrete compressive strength) listed above, doubt about the design class (Section 4.2-4.3), or doubt about compliance with the conditions of use (Section 5), please contact the manufacturer (Pensmore Reinforcement Technologies) or a professional registered design professional and ask for a detailed design in accordance with this report based on your exact specification.